Tech	nical	Bul	letin

NITTO

NTSD-12-005

April 16, 2020

## Load Capacity of Nitto<sup>®</sup> NT05R<sup>™</sup> and NT555<sup>®</sup>RII Tires

Nitto Tire U.S.A. Inc. is introducing the following sizes in the NT05R<sup>™</sup> and NT555<sup>®</sup>RII Drag Radial product line that are designed using the Light Load (LL) standard of the Tire and Rim Association (T.R.A.);

P275/40R17P305/45R18P305/45R17P315/40R18P315/35R17P335/30R18P275/40R18P345/30R19P285/40R18P315/35R20

#### Load Identification

Under the T.R.A.'s designation, tire load is divided into three categories: Light Load (LL), Standard Load (SL), and Extra Load (XL). Each refers to the tire's ability to carry a certain load at a given air pressure. Tires designed for LL, SL, XL duty are usually identified as such on the sidewall.



Figure 1 – Light Load molded into sidewall

**CAUTION!** A Light Load tire carries less load at the same inflation pressure as a standard load tire and has a lower maximum load capacity than the equivalent standard load size. Figure 2 below shows the different load capacities of the three different categories of tires of the same size.




Figure 2 – Tire Load vs. Inflation Chart

### **General Advice for Determining Correct Inflation Pressure:**

"Plus size" tires, including subject tires, may require higher inflation pressures than what is indicated on the vehicle Tire Information Placard or in the vehicle Owner's Manual. Any "plus size" tire should be inflated to a pressure that provides equal or greater load capacity compared to the original equipment (O.E.) tire. Always refer to tire industry load & inflation tables to determine correct inflation values when installing "plus sizes", or contact Nitto Tire for assistance.

# WARNING

Always observe this advice to avoid overloading the tire. Tire overload will contribute to tire fatigue and could lead to tire failure. Tire failure may lead to an accident, which may result in injury or death.

Single Load per tire in pounds:

Size		Tire Load Limit at Various Cold Inflation Pressures						
		PSI	26	29	32	35	36	
P275/40R17	93LL	lbs.	1,235	1,301	1,367	1,433		
P305/45R17	102LL	lbs.	1,609	1,698	1,775	1,874		
P315/35R17	93LL	lbs.	1,246	1,323	1,378	1,433		
P275/40R18	94LL	lbs.	1,290	1,356	1,422	1,477		
P285/40R18	96LL	lbs.	1,367	1,444	1,510	1,565		
P305/45R18	103LL	lbs.	1,554	1,664	1,775	1,874	1,929	
P315/40R18	102LL	lbs.	1,620	1,709	1,786	1,874		
P335/30R18	95LL	lbs.	1,312	1,378	1,444	1,521		
P345/30R19	98LL	lbs.	1,433	1,510	1,587	1,653		
P315/35R20	97LL	lbs.	1,301	1,389	1,477	1,565	1,609	

Figure 3 – T.R.A. Load & Inflation Table

Load and inflation tables are published by The Tire and Rim Association, Inc. 175 Montrose West Ave., Suite 150, Copley, Ohio 44321.

For more information, please contact Nitto Tire U.S.A. Inc.'s Consumer Relations Department at (888) 529-8200.

#### Nitto Tire U.S.A Inc. PO Box 6064 Cypress, CA 90630 www.nittotire.com

4/2020 Rev. 3 Item No. 12-005